
Slim-Line® (1/4") - C - Window/Door Corner Kit Layout Guide



SAFETY FIRST!
Always wear Safety Glasses and applicable Personal Protective Equipment during installation

Time: 2-5 minutes (Average)

Skills: Measuring, Stapling/Screw-Driving, Cutting

Prep: Clear objects from wall area where kits will be installed.

Required Tools:

- Hold-It Stick Roll-on Adhesive
- Chalk Line
- Square-It Tool
- Tape measure (Fabricmate's Measure-It Repositionable Adhesive Tape Measure recommended)
- Power Driver and 1" drywall screws or Staple Gun using 1/4" crown 7/8" leg staples

EASY TO INSTALL:

1. **CUT** template along black dotted line. If panel is free-standing also cut along blue lines so template won't show past frame edge.
2. **MEASURE** to determine location of Window/Door Corner on wall. Use Chalk Line if needed to span a large distance.
3. **USE** Hold-It Stick to attach template to wall using it as a guide. Once positioned, attach Kit Pieces to wall using Hold-It Stick and Square-It Tool.
4. **STAPLE** or screw piece 6 to wall as indicated on template placing staples (⌐¬) as shown every 1/2" to 1" or using 2 screws per piece. Repeat for piece 5.
5. **ATTACH** straight frame (F) pieces (sold separately) to wall in same manner as needed to span between installed kits.

FS005 - Slim-Line® (1/4") - C - Window/Door Corner Kit Layout Guide